

# Page Up or Down

Most skins display page up or down arrows, called spin controls.



These are particularly helpful when using a mouse or touch screen. However when using a remote, the Page Up or Page Down keys are much easier.

The first number displays the current page you are viewing, while the second number displays the total number of pages or screens available in the current window.